

airCentric – Adding a Headrest

Instructions:

Step 1: Locate and mark holes, as shown in the image on the right.

Step 2: Drill two holes with a 5/16" drill bit. Do not go more than 3/8" deep.

Step 3: Align the new headrest bracket and install the two M6x25mm Pan Head fasteners provided, securing the headrest to the chair back.

