

## geoCentric XTB Headrest – Installation Guide

1. Using your hand, feel in the general direction of the two holes, as shown in the diagram to the right. You should feel four ½" holes. Use the two centre holes.
2. Using an awl, soldering iron, or sharp knife, cut away the fabric in this area, exposing the two holes.
3. Align the new headrest bracket and install the two M6x25mm Pan Head fasteners provided, securing the headrest to the chair back.

