



# Adjusting your armrest

## ADJUSTABLE T-ARM WITH PUSH BUTTON ADJUSTMENT




- Locate button on the outside of arm bar.
- Press button inward to raise/lower arm to one of the five desired height.

## ADJUSTABLE T-ARM WITH TURN DIAL ADJUSTMENT




- Locate the height adjustment dial on the outside of arm bar.
- Turn dial clockwise to raise the arm and counter-clockwise to lower the arm to one of the five desired heights.

## ADJUSTABLE T-ARM WITH FINGER TIP ADJUSTMENT



- Locate the height adjustment below the arm pad.
- Pull the lever up and hold to raise/lower arm to desired height.
- Release lever to lock in place to one of the five desired heights.


## TRIGGER ADJUSTABLE T-ARM



- Locate the height adjustment lever on the front of the arm bar.
- Pull trigger lever inward to raise/lower arm to desired height.
- Release lever to lock in place.


# ADJUSTABLE ARMS

## TRIGGER ADJUSTABLE T-ARM




- Pull up on arm pad to disengage lock.
- Drop arm towards the back of the seat pan.
- Lift arm towards the front of the seat pan to engage lock.

## LATERAL ARM PAD ADJUSTMENT




- Simply pull the arm pad inward to your body or push it outward away from the body. 3" of adjustment per arm.

## SWIVEL ADJUSTABLE ARM PAD ADJUSTMENT



- Simply turn the arm pad left or right to desired position.
- The arm pad can be rotated 360°.

## LATERAL ARM PAD ADJUSTMENT



- Simply pull the arm pad inward to your body or push it outward away from the body. 3" of adjustment per arm.

